

Таблица совместимости бритв BRAUN и сменных аксессуаров: сеточек, режущих блоков и кассет.

маркировка сеточек	модели бритв	серия бритв	типы бритв
70S / 9000 Series	790cc, 760cc, 730, 720, 9595, 9585, 9565	Series 7, Pulsonic	5671, 5672, 5673, 5674
51S / 8000 Series	590cc, 570cc, 560, 550, 510	Series 5	5646, 5649, 5751, 5757
51S / 8000 Series	8995, 8990, 8985, 8975, 8970, 8595, 8590, 8588, 8585, 8583	360° Complete, Activator	5646, 5649, 5751, 5643, 5645
32S (серебристая), 32B (черная)	390cc, 380, 370, 360, 350; 340, 320, 310, 300	Series 3 New	5772, 5773, 5774, 5775, 5776, 5777, 5778
31S / 31B / 5000 Series 5000 / 6000 Series	390cc, 370, 5895, 5875, 380, 360, 6550, 6525, 6522, 6521, 6520, 6518, 6515, 6512, 6510, 6015, 6012, 5877, 5874, 5776, 5775, 5774, 5773, 5771, 5770, 5716, 5715, 5665, 5663, 5615, 5614, 5613, 5612, 5611, 5600, 5446, 5444, 5412, 5410, 5314, 5312, 5010	Series 3, Contour, Flex XP, Flex Integral	5474, 5726, 5719, 5424, 5703, 5704, 5705, 5706, 5707, 5720, 5476, 5735, 5736, 5738, 5739, 5724, 5726
30B/ 7000 / 4000 Series	340, 330, 320, 310, 300, 4875, 4845, 4840, 4815	Series 3, SmartControl	5742, 5743, 5747, 5775, 5776, 5777, 5778
30B/ 7000 / 4000 Series	7790, 7785, 7765, 7680, 7650, 7630, 7570, 7540, 7520, 7516, 7515, 7510, 7505, 7504, 7493, 7475, 7015	SyncroPro, Syncro	5491, 5493, 5494
30B/ 7000 / 4000 Series	4775, 4745, 4740, 4715	TriControl	5713, 5714, 5717
10B/1000 Series	190, 180, 170, 1775, 1735, 1715	Series 1, FreeControl	5729, 5727, 5728
11B New	150, 130, 835, 815	Series 1 New	5684, 5683
20B/2000 Series	Z60, Z50, Z40, 2878, 2876, 2874, 2865, 2778, 2776, 2675, 2338	cruZer	5730, 5732, 5733, 5734
Freeglider	6680, 6620, 6610, 5708(?), 5710 (?)	FreeGlider	5404, 5405, 5408, 5410, 5708, 5710
3000 Series	3775, 3773, 3770, 3710, 3615, 3614, 3612, 3610, 3310, 3305, 3105	InterFace, InterFace Excel	5629, 5634, 5635, 5447, 5449
424	5579, 5569, 5567, 5564, 5479, 5470, 5469, 5424, 5419, 3520, 3511, 3020, 3011, 3008	System 1-2-3, micron vario 3, Action line	
428	5563, 5561, 5556, 5428, 5426, 5423, 5422, 5421, 5420	micron 1000, micron 2000	
596	2560, 2540, 2540S, 2060, 2040, 2035, 1512, 1509, 1508, 1507S, 1013, 1013S, 1012, 1008, Shave & Shape	Braun 1000/2000	5462, 5596, 5597
585	4510, 4000 battery	Flex Control	5584, 5473

PocketGo (PocketGo 500)	P40, P50, 550, M-30 P70, P80, P90, 575, 370, M-90	Pocket Shaver, CruZer Twist, PocketGo, MobileShave M-30 CruZer Twist, PocketGo, Pocket, MobileShave M-90	5604, 5609
370, 375	370, 375	Pocket Twist plus, Pocket, E-Razor	5615
CCR2	390cc, 590cc, 760cc, 790cc, 8595, 8795, 8995, 7785, 7765, 7630, 7511, 7526, 7520, 7515	Clean & Charge, Clean & Renew	5772, 5771, 5643, 5646, 5673, 5671, 5493
SCR4	6690, 6680, 6620, 6610	FreeGlider	5708, 5710